

90 cm 4 zone ceramic cooktop

RRP AUS \$999.00

Product Details

FEATURES

Trimless black ceramic glass

Stylish ceramic cooktop

Rotary controls

Hot surface indicator

4 ribbon elements

BENEFITS

Easy to use rotary controls

Rotary controls with stepped settings make it easy to use and easy to determine the heat needed

Contemporary and functional

The Chef range of cooking appliances has all the features you need in a design that you'll love

Easy clean ceramic

Not only does it look great, the durable glass surface on Chef ceramic cooktops is easy to clean, helping you to keep your kitchen looking its best

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	electric
Materials/Colour	black ceramic glass
Knob Finish	black

CONTROLS

Controls of Cooktops	knob
Position of controls	front
Indicators/display	residual heat warning lamps

LEFT REAR ZONE

Left rear zone	ceramic
----------------	---------

DIMENSIONS

Total product height (mm)	46
Total product width (mm)	930
Total product depth (mm)	520
Cut out width (mm)	880
Cut out depth (mm)	490

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	ceramic
Left front Watts	2300
Left front number of cooking zones	1

RIGHT FRONT ZONE

Right front zone	ceramic
------------------	---------

Left rear watts	1200
-----------------	------

Left rear number of cooking zones	1
-----------------------------------	---

Right front Watts	1800
-------------------	------

Right front number of cooking zones	1
-------------------------------------	---

RIGHT REAR ZONE

Right rear zone	ceramic
-----------------	---------

Right rear watts	1200
------------------	------

Right rear number of cooking zones	1
------------------------------------	---

ELECTRICAL SPECIFICATIONS

Connected load KW	6.5
-------------------	-----

Maximum current rating (amps)	27.1
-------------------------------	------

Type of connection	hardwired
--------------------	-----------

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz