

30cm 2 zone black ceramic induction cooktop with touch on glass controls, pause and QuickCook timer (TM) function.

RRP AUS \$1,399.00

Product Details

FEATURES

Pause Pause and restart cooking at the touch of a button	QuickCook Timer Cook steaks and quick meals to perfection every time with the QuickCook count down timer.	Boost Boost up power to cooking zones by more than 25%.	Induction Enjoy the safety, speed and efficiency of induction cooking.
Touch on glass controls	Frameless ceramic glass is stylish and so easy to clean.	Residual heat indicators For added safety, residual heat indicators show activated hotplates and hotplates still cooling down.	Child safety device
Easy cleaning	Perfect heat control		

BENEFITS

Pause when you need to When you're cooking, those pesky interruptions won't be a bother anymore. That's because you can simply pause what you're doing. Just press the Pause icon on your induction cooktop and all operating zones will drop to a Keep Warm mode. And when you're ready to resume, touch the Pause icon again and all zones will return to their previous setting.	QuickCook Timer Now even when things get busy in the kitchen, you'll never lose track when you're cooking. This nifty timer counts down and even turns the zone off. Now you can cook the perfect steak or boiled eggs or any other meal exactly to your liking. You'll never ruin a quick family meal again!
Induction cooking Enjoy the safety and efficiency of induction cooking. Almost twice as fast as gas or electric in transforming energy into heat, you'll save not only time but money too. What's more, induction cooking only generates heat in the cookware, so surfaces around the pot are cool to touch. Therefore the cooking environment remains cooler and safer. The surface is also easy to clean, as any spills are simply wiped away.	Touch on glass controls With flat easy-clean touch on glass controls at your fingertips, you can easily control the heat. So all you need to do is concentrate on preparing the perfect meal.

You can be energy wise

Induction cooking is almost twice as efficient as gas or electric in transforming energy into heat, saving you time and money.

Cooking can be a family experience

With no naked flames or elements the whole family can join in the fun of cooking.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	Induction
Materials/Colour	black ceramic glass
Removable trim (for cleaning)	No

CONTROLS

Controls of Cooktops	touch
Position of controls	front
Functions of Cooktops	timer,Keep warm function,pause
Indicators/display	fault indicator,residual heat warning lamps
Features of Cooktop	safety cut off,electronic timer,safety child lock,hot surface indicator,sound off
Timer of Cooktop	programmable 99min,countdown

DIMENSIONS

Total product height (mm)	46
Total product width (mm)	300
Total product depth (mm)	520
Cut out width (mm)	270
Cut out depth (mm)	490

ELEMENTS/BURNERS

CENTRE FRONT ZONE

Centre front zone	induction
Centre front Watts	1400
Centre front number of cooking zones	1
Centre front diameter	140

CONTROLS

Readable temperature setting	No
------------------------------	----

CENTRE REAR ZONE

Centre rear zone	induction
Centre rear Watts	2300
Centre rear number of cooking zones	1
Centre rear diameter	210

ELECTRICAL SPECIFICATIONS

Connected load KW	3.7
Type of connection	hardwired

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz