

60cm 4 zone PowerReady, a low current enabled induction cooktop, makes upgrading easy. Features 9 power levels plus PowerBoost, simple touch controls and residual heat indicators

Product Details

FEATURES

PowerReady	Powerboost gives you intense heat in an instant	9 power levels	Touch controls
Residual Heat Indicator	Pause function	Child lock	Auto off safety

BENEFITS

Transition to induction? Easy.
Easily upgrade to your PowerReady cooktop with minimal fuss by connecting to standard household power.**For installation please consult a licenced electrician

Simmer, boil or sear? Easy.
Easily adjust the heat with nine power levels, giving you precise control for fast, efficient induction cooking, whether you're simmering, boiling or searing.

Heat in an instant
Powerboost gives you intense heat in an instant so you no longer have to waste time waiting for water to boil or your pan to heat up.

Touch on glass control
Our cooktops have easy to use touch on glass control for a seamless and more responsive cooking experience.

Safe and sound child lock
Know that your family is safe thanks to an added child lock feature that prevents them from starting the cooktop by accident.

Residual heat indicator
For added safety, residual heat indicators show activated hotplates and hotplates still cooling down.

Auto off safety feature
A safety feature which ensures that your cooktop will automatically turn off when cooking zones are unattended or a spill occurs.

Easy to clean
Chef cooktops have easy clean surfaces offering a straight forward solution in the kitchen

Pause when you need to

Press pause to stop cooking instantly, then pick up right where you left off perfect for quick interruptions.

Set it. Forget nothing.

Set cooking times easily with the built-in count down timer and minute minder, helping you stay on top of every dish without overcooking

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	induction
Materials/Colour	black ceramic glass

CONTROLS

Controls of Cooktops	touch
Position of controls	right front
Functions of Cooktops	PowerBoost,auto heat up,automatic switch off,pause,Individual zone timers,Pot detection
Indicators/display	3 level residual heat indicator
Features of Cooktop	safety cut off,safety child lock,hot surface indicator,auto pot sensors,minute minder

DIMENSIONS

Total product height (mm)	46
Total product width (mm)	590
Total product depth (mm)	520
Cut out width (mm)	560
Cut out depth (mm)	490

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	induction
Left front Watts	2300
Left front boost watts	3200
Left front number of cooking zones	1
Left front diameter mm	210

CONTROLS

Timer of Cooktop	countdown,Minute minder
------------------	-------------------------

LEFT REAR ZONE

Left rear zone	induction
Left rear watts	1400
Left rear number of cooking zones	1
Left rear diameter mm	140

RIGHT REAR ZONE

Right rear zone	induction
Right rear watts	1800
Right rear number of cooking zones	1
Right rear diameter mm	180

SHIPPING

Shipping Volume (m3)	0.0336
----------------------	--------

RIGHT FRONT ZONE

Right front zone	induction
Right front Watts	1400
Right front number of cooking zones	1
Right front diameter mm	140

ELECTRICAL SPECIFICATIONS

Connected load KW	4.6
Maximum current rating (amps)	20
Type of connection	hardwired


STUFFING QUANTITIES

40ft HC	1140
---------	------

SHIPPING

Shipping Weight (Kg)	10.0
Pack Dimensions Height (mm)	80
Pack Dimension Width (mm)	700
Pack Dimension Depth (mm)	600

Dimensions



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz